




# Lenovo Ideatab S6000 Battery Replacement

Replacing the battery in order to fix power related problems, such as: failure to power on, random device shutdown, device not holding a battery charge.

Written By: Josiah Speed



## INTRODUCTION

Guide the user in replacing the battery in order to fix power related problems of the Lenovo Ideatab S6000.

---



### TOOLS:

- [Spudger](#) (1)
  - [Phillips #00 Screwdriver](#) (1)
  - [iFixit Opening Tools](#) (1)
-




## Step 1 — Battery



- Remove speaker screens by working them loose with a plastic opening tool. You may need to first loosen them with iFixit tweezers or a craft knife.


⚠ These screens are held in place by glue and are hard to remove. Take your time.

## Step 2



- Remove the 3.14" Philips screws from both spots that were covered.

### Step 3



- Go all around the casing prying the screen away from the backing with a spudger.
- It will make a popping sound each time one of the lock tabs is disconnected.

**⚠ DO NOT USE A METAL TOOL FOR THIS.**


- **i** Take your time as you move all around the device prying the backing off.

### Step 4




- Pull off the plastic covering the battery cable.





## Step 6



To reassemble your device, follow these instructions in reverse order.

